

Lean production is a business system for organizing and managing product development, operation, suppliers, and customer relations that require less human effort, less space, less capital, less material, and less time to make products with fewer defects to precise customer desires. (Lean.Org)

Process Improvement Flow Guide

- Strategic Alignment & VOC
- SIPOC\High Level Map
- Constraint / Gap Analysis
- Value Stream Mapping
- Value Added (NVA)
- Walk the Process
- Spaghetti Diagram
- Ideal State / BPR
- Future State

- Point of Use
- 5S's
- Visual Management
- Standard Work
- Error-proofing
- Quick Change Over
- Total Production Mtc/Admin.
- Leveling / Mixed Model
- Cells / One Piece Flow
- Kanban / Pull

Little's Law

TAKT Time

Available time divided by **customer demand** provides process capability compared to cycle time.

TAKT Time = OT (Net Operating Time) / CR (Cust. Requirements)

Example

One 8 hour shift = 60 Min/hr * 8 hrs = 480 min/shift

Net operation time = 480-30-10-30-10-15= 385 min/shift

TAKT Time = 385/50 = a unit every 7.7 minutes

Breaks = 30 min shift

Lunch = 30 min/shift

Start up meeting = 10 min/shift

End of Shift Clean = 10 min/shift

Customer Demand: 50 units/shift

Machine Setup = 15 min/shift

Little's Law provides an equation for relating Lead Time, Work- in-Process (WIP) and Average Completion Rate

Lead Time = WIP (units) / "Ship" (units per time period)

Example

A quoting department can complete 4 quotes per day (Ship), & there are 20 quotes (WIP) in various stages in the dept. Appling Little's Law: Lead Time = WIP/Ship =20 quotes/4 quotes/day = 5 days

- TOC / Critical Chain
- 5 Why's / Cause & Effect
- Pareto /Control Charts
- Brainstorming

- Action Plan
- Implementation
- Feedback Loop

8 WASTES

Defects

Overproduction

Waiting

Non-Standard over-processing

Transportation

Intellect

Motion

Excess Inventories CELL: A type of lateral organization or process complete operation, where work is organized by outcomes.(Hyer & Brown)

Cycle Time: Avg. time to complete a

process from release. **FIFO:** (First in / First Out) **Kaizen:** Change for good.

Lead-Time: Time to deliver a product from

order.

Process: Organized group of related activities that together create a result of value to customers.

Standard Work: The documentation, communication, and storage of best practices for a particular process by employees performing the work.

WIP: (Work in Process)
TOC: Theory of Constraints

Critical Path: Time constraint, apply TOC. Critical Chain: Resource constraint, apply

TOC.

Safety Sustain Standardize Straighten Sweep

KanBan Cycle Time D = Average Demand Signal=Full SF = Safety Factor $D X(1+SF) X LT \longrightarrow$ Container Kanban Size LT = Kanban Cycle Time Opened (Time for material to be D X(1+SF) X LT +1 replenished once a signal Signal= Kanban Size has been received) Container Empty

Minimum Manning

Estimate # of Workers Needed


Sum of Cycle times / TAKT Time


Facilitator Notes


- Handoffs
- Percent complete and accurate
- Ask WHY 5 times
- Walk the process
- · Brainstorm ideas
- What do you think?
- Ask about waste in non-threatening way
- "Multitasking is worse then a lie"

THE UNIVERSITY of TENNESSEE
















Value-Added Activities

The inherent worth of a product as judged by the customer and reflected in it's selling price and market demand. Lean Lexicon, LEI

Non-Value Added and Waste

- That which does not contribute to what the customer is willing to pay but is required under the current process.
- Does not fit, form, or function.
- Done for internal use.
- Would not pass a line-item veto (by customer internal or external)

Hi-Level Process Map



THE UNIVERSITY of TENNESSEE